



EXPLANATION

-  **Fault**—Dashed where approximately located; dotted where concealed
-  **Boundaries—**
Morongo ground-water basin (approximate)—
Subbasin boundary
-  **Warren ground-water basin boundary**
-  **3,000**  **?** **Water-table contour**—Shows altitude of water table. Contour interval, in feet, is variable; dashed where approximately located, queried where uncertain. Datum is sea level
-  **2,950**  **?** **(Intermediate contour)**
-  **Generalized direction of ground-water flow**
-  **Well in which water level was measured**—
Top number is abbreviated State well number.
Bottom number is altitude of water level,
in feet above sea level. **(P)** indicates pumped well
-  **Hi-Desert Outlets** **Artificial-recharge site and name**